

# **MEMS Structural Reliability and DRIE: How Are They Related?**

AMFitzgerald-Tegal Collaboration

Alissa M. Fitzgerald, Ph.D. | July 27, 2010



**AMFITZGERALD**  
& ASSOCIATES

# Overview

---

- **About AMFitzgerald and Tegal**
- **Motivation for this study**
  - Deep reactive ion etch (DRIE)
  - Brittle material properties
- **Fracture strength of three DRIE recipes**
- **Practical application of strength data**

# Mission

---

## MEMS Product Development




---

**We turn your ideas into silicon.**

# Fully integrated services: concept to foundry

---



- **Complete design and project management**
- **Feasibility and cost analysis**
- **Design optimization using simulation**
- **Process development on 100 mm or 150 mm wafers**
  - Prototype fabrication with own staff engineers at UC Berkeley's Microlab
- **Test system development**
- **Packaging, system integration**
- **Technology transfer to foundries for production**

# Tegal ICP Product Range... From R&D to mass production

Contact Paul Werbaneth: (707) 765-5608  
pwerbane@tegal.com




# Motivation for this study

---


- Many MEMS devices are fabricated by DRIE
- Trench sidewall roughness is a function of DRIE recipe
- Smoother surfaces typically exhibit higher fracture strengths
- How does fracture strength vary with DRIE recipe (sidewall scallop size)?

# Deep Reactive Ion Etch (DRIE) and MEMS

- **Fundamental etch process for fabricating vertical sidewalls, high-aspect ratio structures**
  - **MEMS**
    - Gyroscopes
    - Accelerometers
    - Microphones
    - Etc.
  - **3D structures**
    - Through silicon vias (TSV)
    - Electrical isolation trenches





Source: Chipworks  
Bosch SMB380 3-axis accelerometer




Tegal DRIE for TSV application

# The Bosch DRIE Process


A cyclic process alternating between etch and passivation




$\text{SF}_6$  Plasma



$\text{C}_4\text{F}_8$  Plasma





$\text{SF}_6$  Plasma






# Two types of DRIE surface features

- The cyclic nature of the Bosch process forms an undulating etched sidewall
- Mask edge roughness transferred during silicon etch, forming vertical ridges
  - a.k.a “micro-masking”




# Scallop depth vs. etch rate (for ~ 25% open area)




# Brittle material behavior

- **Ductile materials (metals) fail at yield strength**
  - Well-defined limit
- **Brittle materials (silicon, glass) have a fracture toughness**
  - Strength is a function of flaw distribution (size, location)
  - DRIE creates surface flaws!
- **MEMS structural reliability depends on etched surface properties**


## Ductile Behavior




## Brittle Behavior




# Theoretical stress-flaw size relationship for silicon




# Measure the fracture strength of three different etch recipes



**Scallop depth =  
150 nm**




**1500 nm**




**3500 nm**

# Three different etch recipes: close-up view




Shallower scallops,  
but more apices

150 nm



1500 nm

Which flaws are  
most significant?




3500 nm



## Fourth surface type: the result of poor resist prep


---



# Measuring surface strength: four-point bend specimens

## Simple but ideal test:

- Uniform maximum stress develops on beam outer surface
- Strength calculated analytically from measured fracture load
- No need for inspection or modeling of each individual specimen
  - Cost-effective
  - Efficient



Follows ASTM D 6272-02




# Test specimen fabrication

---

- Test specimens etched using the different DRIE recipes
  - Through-wafer etch of a double-polished wafer
- Design allows easy handling and testing in macro-scale apparatus


**DRIE-etched silicon test beams**  
 $L = 8\text{ mm}$ ,  $b = 300\text{ }\mu\text{m}$ ,  $d = 310\text{ }\mu\text{m}$




# Test apparatus

---

- Specially-designed test fixtures mounted to Instron 5542
- 90° rotation of specimen allows selection of either polished or etched surface
- Measure load to fracture



# Results: Fracture strength distribution vs. DRIE recipe



*Weibull analysis follows ASTM C 1239-07*

# Observations

---

- **Polished surface ~ 2x stronger than etched surfaces**
- **40% difference in characteristic strength across three recipes**
- **Mask preparation influences surface strength**
  - Resist recipe AND etch recipe are important
- **Etch recipes have statistically distinct Weibull parameters**
  - “Figures of Merit” for process control monitoring

# Application of Fracture Strength Data




# Applications for fracture strength data

---

|                             |   |
|-----------------------------|---|
| Foundry/Etch Tool Selection | <ul style="list-style-type: none"><li>• Compare fracture strengths across recipes, etch tools, foundries</li><li>• Make informed purchase decisions</li></ul>   |
| Cost Savings                | <ul style="list-style-type: none"><li>• Informed etch recipe selection to optimize wafer throughput without sacrificing reliability</li><li>• Reduce development time</li><li>• Improve yield</li></ul>     |
| Quality Control             | <ul style="list-style-type: none"><li>• Monitor etch process stability</li><li>• Across-wafer uniformity</li><li>• Diagnose in-process fracture failures</li><li>• Improve mechanical reliability</li></ul> |
| Design                      | <ul style="list-style-type: none"><li>• Reliability simulation, fracture prediction</li><li>• Performance improvements</li><li>• Size reduction</li></ul>   |

# AMFitzgerald Fracture Prediction Methodology

- Identifies where and when a device is most likely to break
- Informed design
- Reduction of time to market: fewer design, fab, test cycles required
- Process IP stays secure: fabrication and fracture of test specimens is all that's needed



# Summary

---

- **Fracture strength varied by 40% across recipes tested**
- **Mask preparation influences surface strength**
  - Resist recipe AND etch recipe are important
- **The methods used here have broad applicability to recipe/tool/foundry selection, quality control and design**
- **Contact Alissa Fitzgerald ([amf@amfitzgerald.com](mailto:amf@amfitzgerald.com))**
  - Information on test services and fracture prediction
  - A copy of the slides



# Acknowledgments

---

- **Brent Huigens, Dawn Hilken, Carolyn White**
- **Tegal: Geneviève Bèïque, Florent Modica, Paul Werbaneth**
- **Instron Corporation: Karl Malchar**



AMFITZGERALD  
& ASSOCIATES